

IBM ThinkCentre A50P (8196) BIOS 程式升級手冊

本手冊介紹 IBM 桌上型電腦A50P-BIOS 如何升級

底下所有內容，僅適用於下列數款IBM桌上型電腦

ThinkCentre A50P

**(Machine-Type: 8192, 8193, 8194,
8195, 8196, 8197, 8432, 8433)**

步驟一：請使用瀏覽器，連結至下列 IBM 台灣網站。

<http://www-306.ibm.com/pc/support/site.wss/document.do?Indocid=MIGR-51058>

IBM Personal computing support - Flash BIOS update - ThinkCentre A50 (type 8320, 8419) / Thin...

檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)

網址(D) <http://www-306.ibm.com/pc/support/site.wss/document.do?Indocid=MIGR-51058> 移至

Country / region [select] | English [change]

IBM

Home | Products | Services & solutions | Support & downloads | My account

Flash BIOS update - ThinkCentre A50 (type 8320, 8419) / ThinkCentre S50 (type 8092, 8183, 8184, 8416, 8417, 8418, 8429) / ThinkCentre A50p / ThinkCentre M50

Personal computing support

Downloads and drivers

Troubleshooting

Hints and tips

Parts information

Publications

Product information

Operating system installation

Important information

Submit a request

Warranty

↓ Applicable countries and regions

This package updates the basic input/output system (BIOS) on IBM ThinkCentre 8092, 8183, 8184, 8185, 8186, 8187, 8188, 8189, 8190, 8192, 8193, 8194, 8195, 8196, 8197, 8320, 8413, 8414, 8415, 8416, 8417, 8418, 8419, 8432, and 8433 systems.

BIOS is programming that controls low-level hardware operations, including interactions with diskette drives, hard disk drives, and the keyboard. The BIOS is stored on a chip. Your computer uses flash BIOS, which can be updated through a program on a flash diskette so that you do not have to replace the BIOS chip to update the BIOS.

NOTE: Make note of any settings you have changed in the BIOS.

步驟二：請找到 Flash BIOS update (Flash from operating system version) , 並請點選「2ajy46usa.exe」, 準備下載BIOS程式。

updated through a program on a flash diskette so that you do not have to replace the BIOS chip to update the BIOS.

NOTE: Make note of any settings you have changed in the BIOS Configuration Utility. These settings may have to be re-entered after

請點選這裡

fer to it during the installation.

File details		
Version:	2AKT46A	
Release Date:	2004/09/20	
File link	File size	File description
2ajt46a.exe	854,954	Flash BIOS update (bootable diskette version)
2ajt46a.txt	14,809	Installation instructions for flash BIOS update (bootable diskette version)
2ajy46usa.exe	1,803,997	Flash BIOS update (Flash from operating system version)
2ajy46usa.txt	13,964	Installation instructions for flash BIOS update (Flash from operating system version)


步驟三：出現下列的新視窗「Terms and conditions」。

步驟三之一：請先用滑鼠取消「Use IBM Download Director」的左方選取方塊。


步驟三之二：後再用滑鼠，點選「I Agree」左方的箭頭符號。



步驟四：出現下列視窗「檔案下載」，並請點選「儲存」。




步驟五：出現「另存新檔」視窗時，請將檔案儲存在C:\ 底下，
檔名為：2ajy46usa.exe，最後才按下「儲存」按鈕。




步驟六：打開電腦的「Windows檔案總管」，並請執行C:\2ajy46usa.exe。




步驟七：出現下列視窗，並請點選「Next」。




步驟八：出現下列視窗，並請點選「I accept the terms」，之後請點選「Next」。




步驟九：出現下列視窗，並請點選「Next」。




步驟十：等待出現下列視窗，並請點選「Finish」。



步驟十一：打開電腦的「Windows檔案總管」，並請執行下列程式：
C:\IBMTOOLS\FLASH\2AJY46US\winphlash.exe



步驟十二：出現下列視窗，並請點選「Flash BIOS」



步驟十三：出現下列警告訊息視窗，請確認下列三件事情之後，再點選「確定」。

- (1) 請確定電腦是用外接電源。
- (2) 在進行下一步驟之前，請儲存尚未存檔的資料，並關閉所有其他應用程式。
- (3) 當BIOS更新完畢之後，本台電腦將會自動關機。

請客戶確認上述三個敘述，並確實執行之後，按下「確定」按鈕，開始進行BIOS更新

