

設定 IBM Personal computing 開機順序

1. PC 重新開機畫面出現 IBM 後按 F1 可進入此畫面

IBM Setup Utility						
Main	Devices	Startup	Advanced	Security	Power	Exit
▶ System Summary				Item Specific Help		
Product Data:				Select the system Summary option to view a summary of the system hardware configuration.		
Machine Type/Model	81832CU		Select the System UUID option to view the system's Universal Unique Indentification (UUID) string.			
Flash EEPROM Revision Level	2AKT34AUS					
Boot Block Revision Level	2A10A					
System Board Identifier	IBM					
System Serial Number	KKAPG6Z					
BIOS Date(MM/DD/YY)	11/21/03					
System UUID						
System Time(HH:MM:SS)				9:50:27		
System Date(MM/DD/YYYY)				10/3/2004		
F1	Help	Select Item	-/+	Change Values	F9	Setup Defaults
ESC	Exit	Select Menu	Enter	Select Sub-Menu	F10	Save and Exit

2.用鍵盤的方向鍵選擇 Startup

3 出現下方之畫面

4.請再選擇 Startup Sequence,按下 Enter

IBM Setup Utility						
Main	Devices	Startup	Advanced	Security	Power	Exit
▶ Startup Sequence			Item Specific Help			
Keyboard NumLock State:			On Off			
Keyboard Speed:			Fast Normal			
Disketteless Operation:			Disabled Enabled			
Keyboardless Operation			Disabled Enabled			
Power On Self Test:			Quick Enhanced			
Power On Logo:			Enabled Disabled			
Option Keys Display:			Enabled Disabled			
Option Keys Display Style :			Normal Legacy			
Startup device Menu Prompt:			Enabled Disabled			
Virus Protection:			Disabled Enabled			
F1	Help	Select Item	-/+	Change Values	F9	Setup Defaults
ESC	Exit	Select Menu	Enter	Select Sub-Menu	F10	Save and Exit

5.出現下方之畫面

6.用鍵盤的方向鍵選擇 **First Startup Device**

7.按下 ENTER 後,則有 Removable,Hard Disk 0,CD/DVD-rom
可選擇

PS:若如下圖則,需先將 Third Startup Device: 設定為 Disabled

First Startup Device: CD/DVD-rom 選項才會出現

IBM Setup Utility						
Startup						
Startup Sequence	Item Specific Help	Item Specific Help				
Primary Startup sequence:		Select the system Summary option to view a summary of the system hardware configuration.				
First Startup Device:	Removable					
Second Startup Device:	Hard Disk 0					
Third Startup Device:	CD/DVD-ROM	Select the System UUID option to view the system's Universal Unique Identification (UUID) string.				
Fourth Startup Device:	Network Disabled					
Automatic Startup sequence:	Enabled Disabled					
First Startup Device:	Removable					
Second Startup Device:	Hard Disk 0					
Third Startup Device:	CD/DVD-ROM					
Fourth Startup Device:	Disabled					
Error Startup Sequence:	Disabled					
Removable Devices						
F1 Help	Select Item	-/+	Change Values	F9	Setup Defaults	
ESC Exit	Select Menu	Enter	Select Sub-Menu	F10	Save and Exit	

8.設定好後 F10